

01	0948 68 NFP	08	INTAKE VALVE
02	0949 68 NFP	04	EXHAUST VALVE
03	0903 46	12	LEVER
04	0907 24	12	GUIDE
05	0942 25	12	VALVE CLEARANCE TAKEUP BALLJNT
06	0950 14	24	VALVE HALF-CONE
07	0951 29	12	VALVE SPRING RETAINER
08	0956 22	12	ENGINE VALVE STEM SEAL
09	0952 67 NFP	12	VALVE SPRING
10	0220 81 NFP	12	VALVE GUIDE IERE REPAR 13,29
	0220 82 NFP	12	2EME REPAR 13,59
11	0226 C6 NFP	12	VALVE SEAT IERE ET 2EME REPAR
70	6946 30	12	PLAIN WASHER 21X30-0,9